11 5/40

DART AEROSPACE LTD	Work Order:	24283	
Description: Window Assembly		Part Number:	D3136-043
THO4.06.09 (1 55.49.14	्र		
Dwg: D3136 Rev. Ø C		Qty:	20
			Page 1 of 1

Step	Location	Procedure	Ву	Date	Qty
1	DC .	Issue Traveler	(A)	05.09.14	20
2	PĞ	Issue P/O: 2008653 Order D3136-3 per Dwg D3136 Supplier: -Canus Material: Polycast II Clear Acrylic sheet per MIL-P-5425 0.125" thick Apply 3M Protective Masking Film both sides Material release note required	K	oskalis.	2 C
3	RG	Receive and Inspect for transit damage Ensure that material release note is attached	CL	X103109	20
4	QC6	Inspect dimensions as per Dwg D3136	2	06.03.10	20
35	GA	Trim back masking film as per Dwg D3136 and apply D3108-9 decals to inside surface of windows.	5 6	06 103 114	い
6	GA	Engrave Part number and Batch number as per Dwg D3136	SB	06/03/14	ون
7	QC5	Inspect work to Step 6	1	06.03.15	20
8	ST	Identify and Stock as D3136-043	CZ	06/03/15	RO
9	AC	Cost / part	al c	De. 03.15	20
10	DC	Close W/O (Inspect Level 21)		Odos 115	20

Rev	Date	Change	Revised By	Approved
Α	04.02.04	New issue	KJ/DS	→#
	·			

